




GlowStep Revolution Tension Adjustment

Your GlowStep Revolution Steps come from the factory preset to a specific torque setting. This can be adjusted to suit your personal preference for ease of use if needed. The Hinge Tension Adjustment bolts are circled in photo below. In order to tighten or loosen the scissor action on the steps simply take two 7/16" wrenches and locate two outside bolts in- between each of the steps. Turn the bolts in very slight increments of 1/16 turns at a time starting at the top then alternating to the other suggested bolts until complete.

Caution: Do not over tighten any one bolt as this causes accelerated wear. When your step is set to your liking, it should begin to slowly open when disengaged by the release lever. If it opens and contacts the ground without assistance the steps can easily be adjuster for better tension.



P: 1.800.246.8132 F: 253.854.8003

1901 Fryar Ave. Sumner WA 98390